



PRY UP HERE

Due to slight differences in land level under the bottom steel you may have gaps between wall panels. These can and should be closed so that you have a tight, closed seam at each joint where panels meet. This is done by prying up on the panels or occasionally,

prying up on the bottom steel where it may be low. The gaps are exaggerated in this diagram for clarity's sake. If bottom steel is leveled to within 1 in. overall you should not have any trouble installing the water walls.





PLYWOOD NAILING SEQUENCE 12 x 20, 12 x 24, 8 x 32, 8 x 40

