

With full bracket remove the wing nut to remove the bottom portion of the bracket. Once bottom is removed you can now use wood screw (Not provided) to attach bracket to the outside of the wood face board of your pool with bracket top resting on your solar deck.