

# SOLAR HEATER STANDARD BYPASS KIT

## Connecting Multiple Units


### Instructions

1. Turn off filter/pump and block off water at BOTH the pool at filter/pump and pool return connections.
2. Disconnect pool return hose at pool connection.
3. To Install bypass kit:
  - a. Install the bypass valve assemble in the hose coming from the filter tank.
  - b. Attach any necessary hose to the "T" connector.
  - c. Connect solar heaters as seen in figure below. Secure hoses with hose clamps (included).

**Note: Additional hoses may be needed to complete installation. Depending on size of the hoses used, 1¼"-1½" hose reducers may be needed. See your local pool supply retailer for additional components.**

4. Unblock water, fully open BOTH bypass valves, and turn on filter/pump.
5. Adjust the bypass valves as needed to achieve desired flow. Listen for straining or restrictive sounds from the pump, check for bulging hoses and/or leaking connections. Adjust valves as needed.

**IMPORTANT: This kit is not intended for in ground pool installations. For in ground installations, please contact a professional installer.**



### Standard Bypass Kit includes

- 1 - Bypass Valve Assembly
- 1 - "T" Connector
- 6 - Hose Clamps