


**- EASY FILL -**

# WINTER POOL PILLOW



- Floats on top of water under cover
- Helps prevent damage due to ice expansion
- Forms pyramid to let water run off cover
  - For round and oval above-ground pools
  - Easy to install
- Instructions on reverse side


size: **4' x 15' - Heavy**

MADE IN BRAZIL

## INSTRUCTIONS: installing the pool pillow

### 1. INFLATE THE PILLOW


Round pools have one pillow. Long oval pools have two or three small pillows or one large pillow. The pillow can be inflated with a vacuum cleaner. Reserve the hose on the vacuum clean blow into the valve on the pillow. Allow just enough air into the pillow to inflate it. Do not over fill or stretch the pillow with too much air.




(Fig 1)

### 2. POSITION PILLOW

- Tie two nylon cords to the grommets on each end of the pillow. (Fig. 1).
- Position the pillow in the center of pool and secure it there by tying the ends of the cords to each side (Fig. 2a and 2b).



tie to decks



(Fig 2a)

Cord can be slid

the vertical column