
COVER PUMP INSTRUCTION MANUAL

IMPORTANT SAFETY INSTRUCTIONS

Warning: to guard against injury, basic safety precautions should be observed, including the following.

1. Read and follow all safety instructions

- 2. DANGER: To avoid getting electric shocks, please pay attention to the safety instructions.
 - Always unplug the pump from the electric outlet before cleaning and or handling.
 - This cover pump is intended for indoor and outdoor use.
 - If any unusual electrical leakage occurs, please turn the power off immediately.
 - · Carefully examine the cover pump after installation. It should not be plugged in if there is water on parts not intended to be
 - Do not operate the cover pump if it has a damaged cord or plug, malfunctioning in anyway, or it's been dropped or damaged in any manner
 - If the plug or receptacle is filled with water, or gets wet, do not try to pull the cord out. Disconnect the power by removing the fuse or turning off the circuit breaker. Only then can you pull the cord out.
 - To avoid the risk of electrical shock be certain that it is connected to a grounded receptacle protected by a ground fault circuit interrupter (GFCI). The user should arrange a "drip loop" as shown in the figure below for each cord connection and the cover pump to a receptacle.




- Do not lift, carry, or pull the pump by the power cord
- Do not replace the pump power cord. Stop using the pump and discard should the power cord become damaged.
- 3. Adults shall be attentive when a child is in the vicinity of the cover pump.
- 4. To avoid injury do not handle the pump when it is hot.
- Always unplug the cover pump when not in use. Do not attempt to clean the unit when it is plugged in. Never pull or tug the power cord to pull the plug from the outlet. To disconnect from the receptacle grasp the plug to remove.
- 6. Do not install or store the cover pump where it will be subjected to weather or temperatures below freezing.
- Do not expose the cover pump to direct sunlight or low temperatures for long periods of time.
- 8. Make sure the cover pump is secure on top of the cover before you attempt to turn it on.



- 9. If an extension cord is necessary, a cord with the proper rating must be used. A cord rated for fewer amperes or watts recommended may cause the pump to overheat. Take care to arrange the cord so that it will not cause harm or injury by unintentional
- Before touching the pool or water, make sure to disconnect all power to the cover pump.
- 11. The cover pump is intended only to be used to remove water from the cover of your swimming pool.
- 12. Do not use the cover pump for other than its intended use.
- 13. Grounding instructions


Warning: risk of electric shock, this cover pump must be grounded to minimize the possibility of electrical shock. The cover pump is equipped with an electric cord having equipment grounding conductor and a grounding type plug. The plug must be plugged into an outlet that is installed, and grounded in accordance with all appropriate codes and ordinances and protected by a Ground Fault Circuit Interrupter. The cover pump is to be connected to a nominal 120 A/C Volt Circuit with a grounding plug that looks like the plug illustrated in the sketch below.

14. Warning: risk of electric shock, do not use the pump if there are people in the pool.




FULL ONE YEAR WARRANTY

Swim'n Play Inc., warrants this product to be free from defects in material or workmanship for a period of one year from the date of purchase. Products which prove to be defective under conditions of normal and proper use which prove to be detective under conditions of normal and proper use during the warranty period because of defective workmanship or faulty material will be replaced or repaired without cherge. For warranty service send the defective product, pre-paid to: Swim'n Play, Inc., 313 Regina Avenue, Rahway, NJ 07065. This warranty gives you specific legal rights, and you may have other rights which vary from state to state.




(B) The illustration picture enclosed below is an installation example.



- (C) Connect a garden hose to the output of the
- (D) Place the opposite end of the garden hose in an area away from the pool where you want the water to drain too.
- (E) Place the pump in the deepest water area on top of the cover.
- (F) Connect the power cord from the cover pump to an approved outlet. If an extension cord is necessary, a cord with proper rating should be used. A cord rated for less amperes or watts than the appliance rating may overheat. Care should be taken to arrange the cord so that it will not be tripped over or pulled.
- (G) Don't let the cover pump operate after the water is removed from the cover. The unit is cooled by pumping the water off the cover and will overheat if left to run.
- (H) This cover pump has been investigated for draining swimming pool covers only.



313 Regina Avenue Rahway, New Jersey 07065 Phone: (732) 574-1500 • Fax: (732) 574-1551 www.swimnplay.com



OPERATION AND MAINTENANCE

To clean the pump

Unplug the pump from electrical outlet. Disconnect the Garden hose from the output. Use a small brush or stream of water to remove any debris from the pump

If the pump fails to run, or an abnormal noise if heard, check the following.

First disconnect the power supply.

Check the circuit breaker, or try a different outlet to make sure that the pump is getting electrical power.

Check the pump discharge and hose for kinks and or obstructions

Algae buildup can be flushed out with a garden hose.

Remove the pump front cover and plate to access the impeller area. Turn the rotor to ensure it is not broken or jammed. Use your hand to grip the impeller, gently pull the impeller/rotor assembly out of the housing. Rinse the impeller/rotor assembly and the cavity with clean water. If breakage or surface damage is found, contact the manufacturer for a replacement part.

Check the water level to make sure the pump is completely submerged.